

AREBOS

3D Floor Fan Air Circulator 55W

AR-HE-LZBV55W



Follow all safety precautions in this user manual to ensure safe use.



Thank you for your trust in AREBOS.

Table of contents

1. Introduction and safety instructions	3
1.1 Introduction.....	3
1.2 Symbol explanation	3
1.3 General safety instructions.....	4
1.4 Specific safety instructions	5
2. Use	6
2.1 Control Panel	6
2.2 Select Blower Level.....	6
2.3 Mode button	6
2.4 Setting the timer.....	6
2.5 Angle of inclination.....	7
2.6 Oscillation	7
2.7 Power Off	7
2.8 Remote control.....	8
3. Specifications	8
4. Cleaning and storage	9
5. Environmentally friendly disposal	10
5.1 Disposal and packaging	10
5.2 Disposal of WEEE	10
EU Declaration of Conformity	11

Thank you for purchasing our product. Please read the user manual carefully before using the product for the first time. If you leave the product to a third party, this operating manual must be handed over with it. Protect yourself and others by following all safety information, warnings, and precautions. Failure to follow the instructions may result in injury and/or damage to the product or objects. Keep the instruction manual for future reference. The drawings in this manual may not match the physical objects. Please refer to the physical objects.

1. Introduction and safety instructions

1.1 Introduction

- This instruction manual is intended to familiarize you with the installation, use and maintenance of the device. To install the device safely and correctly, please read the user manual **before** you begin.
- Check the device for damage in transit. Report any damage immediately to the transport company with which the product was delivered.

1.2 Symbol explanation



A CE marking can be used to indicate that a product complies with the legal provisions of European legal standards and may therefore be traded within the European Community.


Warning! Read the safety regulations carefully. Failure to comply with safety precautions can lead to serious injury or damage. Keep the instruction manual safe.



Take special care when using this item.



Warning of electrical voltage!




Note: Unplug!



This product must **not** be disposed of with household waste!



Insulated housing (protection class II)!



Warning! Do not stick fingers and other limbs into the fan housing!



1.3 General safety instructions

- Your safety is our top priority. So please make sure you read the user manual **before** installing and using the fan. If you are unsure about any of the information in this manual, please contact the dealer from whom you purchased the device.
- **⚠ CAUTION:** Read all safety and usage instructions. Failure to follow the safety instructions and instructions may result in electric shock, fire and/or serious injury. Keep all safety and usage instructions for the future.
DO NOT **use the product** if you have not already read the user manual.
- Make sure you have read the user manual thoroughly and understand the contents before you start the installation.
- The instructions are in the interest of your safety.
- Read the instructions carefully. It contains important information for the use, safety and maintenance of the device. It should be carefully stored and, if necessary, passed on to subsequent users.
- The device may only be used for the intended purpose in accordance with these instructions for use.
- This device can be used by children 8 years of age and older, as well as by persons with reduced physical, sensory or mental abilities or lack of experience and knowledge, if they have been supervised or instructed about the safe device and understand the resulting dangers.
- Keep the device and its supply line out of the reach of children under 8 years of age.
- Children are not allowed to play with the device.
- Cleaning and user maintenance must not be carried out by children without supervision.
- If the connection cable of this device is damaged, it must be replaced by the manufacturer's central customer service or a similarly qualified person. Improper repairs can result in considerable dangers for the user.
- Before commissioning, check the device and its connection cable as well as accessories for damage.
- Do not use the device if it has visible damage.

- Before connecting to the power supply, make sure that the electrical voltage indicated on the rating plate matches the voltage of your socket. Only use sockets with a safety contact.
- Do not crush the connecting cable, do not pull over sharp edges or hot surfaces. Do not use lead wire for carrying.
- If the mains connection cable of this device is damaged, it must be replaced by the manufacturer or a similarly qualified person to avoid hazards.
- Turn off the appliance before disconnecting it from the power supply.
- Unplug the appliance after each use, in case of malfunctions during operation and before each cleaning of the appliance.
- Never pull the plug out of the power cord or with wet hands.
- Make sure that the device has good stability during operation and cannot be tripped over the power cord.
- Never use the device after a malfunction, e.g. if the device has been thrown into water, dropped or damaged in any other way.
- The manufacturer assumes no responsibility for incorrect use caused by non-observance of the instructions for use.
- Modification or modification of the product impairs product safety.
- All modifications and repairs to the device or accessories may only be carried out by the manufacturer or persons expressly authorized by him for this purpose.
- Make sure that the product is operated from an outlet that is easily accessible so that you can quickly unplug the device in an emergency.
- If possible, do not use extension cords. If this is unavoidable, only use GS-tested, splash-proof, simple extension cords (no multiple sockets) that are designed for the power consumption of the device.
- To avoid dangerous electric shock, never splash or pour water on the device.


1.4 Specific safety instructions

- The appliance is intended for household use or similar purposes only. It may not be used for commercial purposes!
- Please use the product only in its intended manner.
- Any other use may result in damage to the product or in the environment of the product.
- The device is only suitable for indoor use.
- Make sure that the device has good stability during operation and that the power cable does not become an obstacle or tripping hazard.
- Do not leave loose, small or light objects near the device. These can be sucked into the interior of the device.
- The device must not be used in the bathroom.
- Don't let the cool air blow you directly and don't let the air in the room get too cold. Discomfort and damage to health can be caused.
- Do not place plants or animals directly in the cool airstream. Animals and plants can suffer from the cool airflow.
- Only operate with the cable fully rolled out!
- Never block the air inlet or outlet. Do not operate the device covered.
- Never use the device without a protective grille.
- Keep the device away from televisions and radios to avoid electromagnetic interference.
- Do not run the cable under the carpet or other flammable materials.
- Do not touch the device or control panel with wet or damp hands.

2. Use

- Place the fan on a flat, straight surface.
- Connect the fan to the power supply.
- Press the on/off button on the remote control or control panel to turn on the fan.

2.1 Control Panel



2.2 Select Blower Level



- Press this button to switch to the desired fan level (1-4). The LED of the corresponding blower level lights up.

2.3 Mode button



- Press the mode button and you can choose between sleep mode (gentle ventilation) and "storm" mode (highest level).

2.4 Setting the timer



- Press the timer button to set the timer in hours (1→2→3→4→5→6→7→off). The LEDs of the corresponding number of hours light up.

Timer Time	1 hr LED	2 hr-LED	4 hr LED
1 hour	At	From	From
2 hours	From	At	From
3 hours	At	At	From
4 hours	From	From	At
5 hours	At	From	At
6 hours	From	At	At
7 hours	At	At	At
From	From	From	From

2.5 Angle of inclination

- Press the tilt angle button to tilt the fan head. The fan head moves from top to bottom and back again until you stop it by pressing the button again. He then remains in the stopped position.



2.6 Oscillation

- Press the oscillation button on the remote control or control panel to swivel the fan head. The fan head moves from right to left and back again until you stop it by pressing the button again. He then remains in the stopped position.



2.7 Power Off

- Press the power button on the remote control or control panel to put the fan into standby mode. Disconnect the power plug from the power supply to turn off the fan.



2.8 Remote control



- The same symbols and symbol descriptions apply to the remote control.

3. Specifications

Model	AR-HE-LZBV55W
Manufacturer	Canbolat Vertriebsgesellschaft mbH
Type	Floor fan / air circulator
Voltage & Frequency	220-240 V / 50-60 Hz
Nominal Consumption /Watt	55 W
Airflow	7.5 m/s
Number of fan levels	4 levels
Timer function	1-7 hours programmable
Noise Level (dB(A))	≤ 55 dB(A)
Swivel / Oscillation	Horizontal 65°, Vertical 85°
Class	Class II (insulated)
Dimensions (L x W x H)	285 x 285 x 751 mm
Weight	3.3 kg
Standard for Measurement / Conditions	EN 6070427
Note on disposal	WEEE-compliant disposal in accordance with EU Directive
Diameter headboard	226 mm
Number of fan blades	5
Height adjustable	Yes
Connection	VED Double Round Plug
Material Cable	Copper

Cable length	1.8 m
For room sizes up to	15 m ²
Max. Range Remote Control	3 m
Color	White

4. Cleaning and storage

- Clean the fan regularly.
- Never submerge the cord and the device in water or rinse it under running water.
- **Warning:** Always unplug the device before moving or cleaning it.
- Unplug the device and wait for the blower to stop before starting cleaning.
- Use a vacuum cleaner to remove dust and other debris from the protective grille.
- Use a damp cloth to clean the surface of the device.
- The following agents must **not** be used for cleaning: gasoline, paint thinner, or other chemicals.
- Allow the fan to dry completely before the next use.
- Leave the fan completely assembled for storage.
- Store the fan in a cool, dry and safe place away from children and animals when you are not using the fan for long periods of time. The appliance must not be stored in a hot place or under direct sunlight.
- Ideally, store the fan in its original packaging.

5. Environmentally friendly disposal

5.1 Disposal and packaging

The packaging of your device is made of materials necessary to guarantee effective protection during transport. These materials are fully recyclable and thus reduce the environmental impact. Dispose of the packaging in a bin for recyclable materials.

5.2 Disposal of WEEE

WEEE must be disposed of in accordance with the guidelines and the regulations of local waste disposal. Contact your local administration about the address of the nearest recycling center and deliver your device there.



The symbol of the crossed-out trash can on a waste electrical or electronic device means that it must not be disposed of in household waste at the end of its life. Collection points for waste electrical and electronic equipment are available in your area for free return. You can get the addresses from your city or local government. You can www.arebos.de find out about other return options we have created on our website.



The separate collection of waste electrical and electronic equipment is intended to enable the reuse, recycling or other forms of recycling of waste equipment, as well as to avoid the negative consequences of disposal on the environment and

human health.

Note on battery disposal

The symbol of the crossed-out trash can on batteries or accumulators means that they must not be disposed of in household waste at the end of their service life. If batteries or accumulators contain mercury (Hg), cadmium (Cd) or lead (Pb), you will find the respective chemical symbol below the symbol of the crossed-out trash can. They are legally obliged to return old batteries and accumulators after use. You can do this free of charge at the retail store or at another collection point near you. Addresses of suitable collection points can be obtained from your city or local government.

Our customer service number: Tel. +49 (0) 931 9080 3000

Fax: +49 (0) 931 4523 2799 / E-Mail: info@arebos.de

Canbolat Vertriebs GmbH • Gneisenaustraße 10-11 • 97074 Würzburg

EU Declaration of Conformity

We, the

Canbolat Vertriebs GmbH, Gneisenaustraße 10-11, 97074 Würzburg, Germany

We hereby declare that the devices referred to below comply with the relevant essential safety and health requirements of the EU directives due to their design and construction as well as in the designs placed on the market by us.

Product Name: AREBOS 3D Floor Fan Air Circulator 55W

Item number: 4260627421466

Model Number: AR-HE-LZBV55W

If the device is modified without our consent, this declaration of conformity loses its validity.

Guidelines

This device complies with the following EU/EC directives:

2014/30/ EU EMC Directive

2014/35/ EU Low Voltage Directive

2009/125/ EC Ecodesign Directive

2011/65/ EU RoHS Directive

2012/19/EU – WEEE Directive (Disposal Obligation)

Date/Signature Manufacturer/Location: Würzburg,

28.07.2025



Signature:

Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

Representative of this Instructions for Use/Technical Data:

Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

Office Address:

Canbolat Vertriebs GmbH

Gneisenaustraße 10-11

97074 Würzburg

Return address can be found in the imprint: <https://www.arebos.de/impressum/>

Sales tax identification number: DE 263752326

The court of registration in the commercial register is Würzburg, HRB 10082

WEEE-Reg.-No. OF 61617071